

Libera



Understanding Earth's Energy Budget

LASP • JPL • LBL • UA • CSU • UM • NIST • NOAA • Ball • SDL

The Libera Instrument and Calibration and Characterization Concepts


Dave Harber & Libera Team




CERES and Libera

In order to maintain seamless data continuity Libera shares many key design features with CERES

CERES



Libera





Justification for CERES Similarities

*Must share key instrument characteristics
in order to extend the CERES data record*

Similarities

- Cross-track scanning
- Optical design
- Point-spread function
- Channels and spectral-response functions
 - Short Wave Channel (SW)
 - Long Wave Channel (LW)
 - Total Channel




Justification for Differences

In order to improve accuracy, stability, and capability

- New type of detector
 - New technology permits higher accuracy and improved stability and easier manufacturability
- New internal calibration sources
 - Add spectral tracking of SW channel, improve long-term stability
- Additional channel
 - Split Shortwave Channel (SSW)
 - Provide insight into SW scattering and absorbing processes
- Wide FOV Camera
 - Test independent scene identification, ADM generation, work towards self-contained observation system




High-Level Overview







Radiometer and Calibrator Overview






Radiometers





Telescope Implementation

- The primary mirrors of all four telescopes are all diamond-turned from monolithic aluminum plate
- Telescopes are co-aligned prior to detector integration
- This design provides excellent thermal and alignment stability







Telescope Optical Design: Field Stop

- Libera field stop is same shape and angular size as CERES
 - Hexagonal $2.6^\circ \times 1.3^\circ$
- Allows Libera to match CERES PSF

Field Stop



Resulting Point-Spread Function





Detector

CERES

Open-loop bolometer

- Detector temperature changes
- Incident power is readout as a resistance change
- Time constant dependent on heat capacity and thermal impedance to the heat sink
- Black paint optical absorber

Libera

Closed-Loop Electrical Substitution Radiometer (ESR)

- Detector temperature is constant
 - Power dissipated in the detector is adjusted to maintain a constant temperature
- Incident power is readout as a change in electrical replacement power
- Time constant is dependent on internal detector thermalization
- Vertically-aligned carbon nanotube (VACNT) optical absorber




NIST Sources & Detectors Group

- NIST Boulder Sources & Detectors Group has lead the development of these detectors
 - LASP has been working with NIST on VACNT detectors since 2014
- ~1 month from silicon wafer to detectors
 - All fabrication occurs at NIST Boulder


Boulder Microfabrication Facility



VACNT SEM Image



Patterned VACNT



VACNT Growth System







Open vs Closed Loop Comparison

- Demonstration of Open and Closed-Loop (ESR) operation
- This is actual measurement data taken with the same detector

Open Loop




Closed Loop






WFOV Camera



- 124° FOV
- 555 nm bandpass, 20 nm FWHM
 - Matches VIIRS M4 Band
- Allows multiple observations of the same location with different viewing zenith angles
- More details in next talk



On-Orbit Calibrations/Stability Monitors






On-Orbit Calibrations/Stability Monitors

- SW Calibrator
 - Six discrete illumination wavelengths: 375, 405, 469, 660, 810, 1550 nm
 - Illumination is tracked with a replica of the total radiometer
 - Only views the SW Cal illumination, nothing external to the instrument
- LW Calibrator
 - Flat plate blackbody with VACNT high emissivity coating
- Solar Diffuser
 - Provides no spectral information, independent check for SW Calibrator
 - Three-surface Spectralon diffuser
 - Vary duty cycle use between faces to allow characterization of Spectralon degradation
- Lunar Views
 - Provides no spectral information, another independent check



SW Calibration System

- A folding mirror directs the illumination from the SW LED source to either the SW cal radiometer or the science radiometers
 - 45° angle of incidence, 90° reflection
- Provides on-axis illumination of each science radiometer






Libera Measurement Equation and Ground Calibration Plan



Libera Radiometer Measurement Equation

$$L = \frac{1}{R_M^2(\lambda)T_F(\lambda)\alpha(\lambda)} \frac{P(\lambda) - P_{DS}}{A\Omega}$$

Symbol	Term	Units
$R_M(\lambda)$	Telescope Mirror Reflectivity	-
$F_T(\lambda)$	Filter Transmission	-
$\alpha(\lambda)$	VACNT Optical Absorption	-
L	Radiance	W m ⁻² sr ⁻¹
$P(\lambda)$	Measured Power	W
P_{DS}	Deep-Space Measured Power	W
A	Collection Area	m ²
Ω	Solid Angle	sr





Spectral Response Separation

$$L = \frac{1}{R_M^2(\lambda)T_F(\lambda)\alpha(\lambda)} \frac{P(\lambda) - P_{DS}}{A\Omega}$$

Spectral Response Function

Filtered Radiance

- The spectral response functions are measured during the Libera calibration
- The level 1B Libera data product is this value
- The unfiltering process uses these spectral response functions in the generation of higher-level data products



Radiometric Calibration Goals

$$L = \frac{1}{R_M^2(\lambda) T_F(\lambda) \alpha(\lambda)} \frac{P(\lambda) - P_{DS}}{A\Omega}$$

Spectral Response Function

Filtered Radiance

The goal of the Libera radiometer ground calibrations is to:

- Populate the measurement equation to allow accurate calculation of filtered radiance
- Measure spectral response functions to allow for unfiltering



Radiometer Calibration Overview

- Component-level
 - Component-level testing of flight components will:
 - Update values in the filtered radiance measurement equation
 - Spectral response functions generated from spectral measurements of components
- Detector-level
 - Electrical calibrations
 - Populate filtered radiance measurement equation
 - End-to-End testing of the detectors
 - Test time response, non-equivalence
- Radiometer-level
 - Validate and adjust filtered radiance measurement equation
 - Validate and adjust the spectral response functions
- Validation
 - *Independent check* performed at SDL to validate the filtered radiance measurement equation and spectral response functions




Current Design

Filtered Radiance
Measurement
Equation Values

Symbol	Term	Value	Units
A	Radiometer Area	1.78×10^{-4}	m^2
Ω	Solid Angle	7.72×10^{-4}	sr
V	Reference Voltage	TBD	V
R	Thermistor Resistance	TBD	Ω
R'_T	Top Resistor + MOSFET $R_{DS(on)}$	TBD	Ω
Z_H/Z_R	Electrical/Optical Equivalence Ratio	1	-

Spectral Response
Functions





Telescope Component-Level Calibrations



Telescope Component-Level Calibrations

- Mirror figure
 - Check against the design
- Telescope imaging performance
 - Check against the design
 - Measurement of focal length
 - Input to the solid-angle
- Area
 - Measure clear aperture
- Field-stop
 - Measurement of dimensions
 - Input to the solid-angle



These measurements will be used to update filtered radiance measurement equation



Optical Witness Samples

Witness samples of mirror, filters, and VACNT coatings will be fabricated alongside the flight parts

- Mirrors
 - Flat 25-50mm diameter mirrors
 - Spectral reflectivity will be measured at NIST, LASP, and PTB
- Filters
 - Flat 25mm diameter filters
 - Spectral transmission will be measured at NIST, LASP, and PTB
- VACNTs (from detectors and LW blackbody)
 - Flat 25-50mm diameter samples
 - Spectral reflectivity will be measured at NIST, LASP, and PTB
 - Emissivity will be measured at PTB



These measurements will be used to update the spectral response functions



- PTB
 - German national metrology institute
 - They will provide spectral reflectivity and emissivity measurements beyond 25 μm
 - NIST currently traceable out to 25 μm
- What will be tested at PTB
 - Witness samples of
 - Mirrors
 - Filters
 - VACNT coatings
- PTB calibrations will improve the accuracy of the IR spectral response functions

Example PTB Spectral Emissivity Measurement:


Int J Thermophys (2017) 38:89
DOI 10.1007/s10765-017-2212-z



TEMPMEKO 2016

High-Accuracy Emissivity Data on the Coatings Nextel 811-21, Herberts 1534, Aeroglaze Z306 and Acktar Fractal Black

A. Adibekyan¹ · E. Kononogova¹ · C. Monte¹ · J. Hollandt¹





End-to-End Calibrations



End-to-End Radiometer


- The four science telescopes + SW Cal radiometer
 - Integrated with detectors
- Mounted on 4-axis stage in vacuum chamber

Measurements


- Radiance Detector-based
 - SI-Traceable radiance detector standard mounted next to radiometers
 - Planar Bolometric Radiometer for Radiance (PBR-R)
 - Pair of precision apertures spaced by known distance
 - VACNT ESR detector
 - Illuminate with collimated beam uniform radiance source
 - Collimated integrating sphere
 - Sphere fed with tunable laser
 - Calibrate radiance with PBR-R, check with radiometers
- Source-Based
 - Measure absolute IR radiance from precision ambient temperature blackbody



End-to-End Radiometer: Detector-Based




- Translated between PBR-R and Radiometers
 - Radiometer under test





End-to-End Radiometer: Detector-Based

- Translated between PBR-R and Radiometers
 - PBR-R under test





Planar Bolometric Radiometer for Radiance

- Planar Bolometric Radiometer for Irradiance (PBR-R)
- Pair of precision apertures
 - Separate by a precision distance
- Ambient-temperature VACNT ESR detector

Current estimated measurement uncertainty:

Term	532 nm k=1 [%]	10 microns k=1 [%]
Aperture Areas	0.01	0.01
Aperture Separation	0.02	0.02
Aperture Alignment	0.02	0.02
Optical Absorptance	0.005	0.100
Non-Equivalence	0.05	0.05
Electrical Power	0.005	0.005
<i>Total</i>	<i>0.06</i>	<i>0.12</i>




Detector-Based Uncertainty

- The uncertainty of the detector-based calibration derived from
 - Detector uncertainty
 - Stability and uniformity of illumination
 - Uncertainty in the inter-comparison
- Detector based calibrations will be used from 0.3-11 μm
 - Investigating sources beyond 11 μm
- At a specific wavelength we are also measuring the spectral response function at that wavelength

Term	532 nm k=1 [%]	10 microns k=1 [%]
PBR-R Uncertainty	0.06	0.12
Radiance stability	0.08	0.10
Radiance uniformity	0.10	0.10
Total	0.14	0.18



Detector-Based Calibration Wavelengths



Blue indicates currently achievable laser wavelengths


- Continuous coverage to 4 μm
- QCL and CO₂ lasers to 5-11 μm
- Gas THz laser at 100 μm (lines at 97, 119, 184 μm)
- Investigating additional laser and narrow-band sources



Source-Based Uncertainty: LW, Total

- The uncertainty of the source-based calibration derived from:
 - 320K Blackbody, Radiance = $189 \text{ W m}^{-2} \text{ sr}^{-1}$
 - Emissivity = 0.999 ± 0.001
 - Temperature Uniformity & Accuracy 0.05°C
 - 90K Blackbody, Radiance = $1.1 \text{ W m}^{-2} \text{ sr}^{-1}$
 - Emissivity = 0.9 ± 0.1
 - Temperature Uniformity & Accuracy 1°C
 - Broadband measurement

Term	k=1 [%]
300K Blackbody Radiance	0.12
90K Blackbody Radiance	0.07
Radiometer Stability	0.1
Total	0.17







Spectral Response Functions

- Spectral Response Functions

- A value and uncertainty as a function of wavelength for all channels

$$L = \frac{1}{R_M^2(\lambda)T_F(\lambda)\alpha(\lambda)} \frac{P(\lambda) - P_{DS}}{A\Omega} \quad \frac{1}{R_M^2(\lambda)T_F(\lambda)\alpha(\lambda)}$$

- Measured at the component-level
- Validated during end-to-end






WFOV Camera Calibration

Libera WFOV Camera Ground Calibration

- Radiometric Calibration ($<5\%$)
- Flat Field ($<1.5\%$)
- Filter Spectral Response
- Image Distortion
- Detector Linearity
- Dark Current (Temperature)
- Stray light






Libera WFOV Camera On-Orbit Calibration

- In camera LEDs
- Leverage VIIRS M4 for flat field (e.g. Sahara)
- Pseudo-Invariant Calibration Sites (PICS)
- Monthly Lunar Observations
- Monthly Upper Atmosphere Limb Observations

Libya-4



Lunar

Upper Atmosphere



Summary

- Libera has been designed to:
 - Maintain CERES continuity
 - Advance instrument accuracy and stability
- Instrument design being refined as we move towards PDR
- The instrument calibration concept has been defined
 - Currently refining the calibration plan and estimated uncertainties